

# Security Keypad Instruction

This is dual channels security keypad.

Channel 1 is " ◀ " key (Original factory Code is 11)

Channel 2 is " ▶ " key (Original factory Code is 22)

## 1. How to change the original factory code?

("11"and "22" is the original factory code, for example, If the combination "1234" is the new code for channel1 and the combination "4567" is the new code for channel 2.)

For channel 1

- Press "0" key and hold
- Press " ◀ "key (at same time, the key pad will sound a long " tick".)
- Release " ◀ " key and "0" key
- Input the original factory code "11" then press the " ◀ " key
- Input the new code "1234" then press the " ◀ " key
- Input the new code "1234" then press the " ◀ " key again.

The keypad will sounds a long "tick" means the new code modification is successful.

For channel 2

- Press "0" key and hold
- Press " ▶ "key (at same time, the key pad will sound a long " tick".)
- Release " ▶ " key and "0" key
- Input the original factory code "22" then press the " ▶ " key

- Input the new code "4567" then press the " ▶ " key
- Input the new code "4567" then press the " ▶ " key again .

The keypad will sounds a long "tick" means the new code modification is successful.

2. How to change the old code to new code ( The combination "1234" is the old code, for example "4321" is the new code) .

The method is same as above instruction.

- Press "0" key and hold
- Press " ◀ "key (at same time, the key pad will sound a long " tick".)
- Release " ◀ " key and "0" key
- Input the original factory code "1234" then press the " ◀ " key
- Input the new code "4321" then press the " ◀ " key
- Input the new code "4321" then press the " ◀ " key again.

The keypad will sounds a long "tick" means the new code modification is successful.

3. Code to opener ( For example the above password : "4321")

- Press code key on the openers, the openers will be on the coding stage.
- Input the key pad password "4321" ,then press" ◀ " key
- Repetitive the above operation: Input the keypad password "4321" ,then press " ◀ " key
- The opener code light will be glint, it means code with opener successfully.
- Input "4321" then press" ◀ " to confirm if it can control the opener.

#### 4. How to do when forget the password on key pad?

- Use tool to open the keypad, you can see the electrical board.
- Press the key on the PCB ,holding 5 seconds. The keypad will sound a long tick ,the password has been returned the Original factory code ( 11 and 22).

#### 5. Notice:

1. The new code can't be eight numbers. The keypad will sound 5 times short "tick" which means you input more than 8 numbers code or input different new code while confirm the new code stage.

#### 2. Audible signal

#### status

1 short beep	Keypad tone
1 long beep	Auto power-off
3 long beeps	Modification confirmed
5 short beeps	Error during combination input or combination edit operation
10 rapid beeps	Battery low warning signal New batteries required